


Fountain Pump Assembly Instructions

Diagram and instructions will vary depending on fountain.

1. Place pedestal on level surface.
2. Align shell on top of pedestal as shown.
3. Attach tubing to statue and pump and place in pump basin as shown. **Note:** Water flow can be adjusted on pump. When flow adjustment is needed unplug pump and adjust flow.
4. Run power cord through back slot in shell.
5. Place statue over the pump basin.
6. Fill shell with water to dotted line as shown in picture, approximately 3" from the lip.
7. Plug in pump after it is fully submerged in water.
8. For outdoor use, drain water completely before the onset of freezing temperatures to avoid damaging the pump.



- A. Pedestal
- B. Shell
- C. Tubing
- D. Pump
- E. Pump Basin